TAD-705

Cat. No. 43-705

QUICK REFERENCE

Setting the Day and Time

1. Hold down **STOP** until the TAD beeps once. Then repeatedly press **DIAL** until **SUNDAY** appears. Repeatedly press ◀◀/▲ to select **AM** or **PM**.
2. Press ▼/▶▶, then repeatedly press ◀◀/▲ to set the correct hour.
3. Repeat Step 2 to set the minute, month, date, and the day of the week. Press **DIAL** then **STOP** to return to the time display.

Recording an Outgoing Message

1. To record the OGM 1 (or OGM 2) message, hold down **OGM 1** (or **OGM 2**) until the TAD beeps and the timer starts counting. **OGM1 RECORDING** (or **OGM2 RECORDING**) appears on the display.
2. Speak in a normal voice from about 8 inches in front of the TAD. When you finish, press **STOP.**

Recording a Memo

Press **MEMO** and quickly release it. Speak in a normal voice from about 8 inches in front of the TAD. When you finish, press **STOP**.

Setting the TAD to Answer Calls

- Press **ANSWER**. The TAD says “Answer on,” beeps once, and the HOLD/ANSWER indicator lights.
- To set the TAD to not answer calls, press **ANSWER** again. The TAD announces “Answer off,” beeps once, and the HOLD/ANSWER indicator turns off.
- To set the TAD to announce-only, be sure the TAD is set to answer calls then press **OGM 2**. The TAD says “Announce only,” and **ANS ONLY** appears on the display.

Playing Messages

To play all messages, press **PLAY**.

To play only new messages, hold down **PLAY** for 2 seconds.

Deleting Messages

- To delete a single message, press **DELETE** while the message is playing.
- To delete all messages, stop playback and hold down **DELETE** until **dEL ALL** appears, then press ▼/▶▶.

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

05A00 Printed in China